



STEP 1: Present Phone


Phone




CS 3xx




CS 290




CS 290-U



CS 410 / 410-U



DECT 300



DECT 400

STEP 2: Required Connection Cord

Connection Cord already included!

Not possible!

STEP 3: Selecting the Headset


Headset - Cordless

Electronic Hookswitch EHS/DHSG
= to answer and end calls even when you are away from your desk

Two conditions:

- 1) Elmeg CS 290-U or Elmeg CS 410 or Elmeg CS 410-U
- 2) **GN 9350 + EHS-cord** (P/N: 14201-10) or **GN 9120 EHS** or **GN 6210 + EHS-Adapter** (P/N: 85-00011)

GN 9300




GN 9350
- for hardphone and PC
P/N: 9356-607-101

GN 9330
- only for hardphone
P/N: 9337-508-101

GN 9330 USB
- only for PC
P/N: 9337-509-101

Electronic Hookswitch EHS only with GN 9350 and EHS-Cord for GN 9350
(order separately)
=> EHS- conditions see left column
P/N: 14201-10

GN 9120



GN 9120 MidiBoom
P/N: 9120-48-01


GN 9120 FlexBoom, NC
P/N: 9120-28-01

GN 9120 MicroBoom
P/N: 9120-30-01

GN 9120 EHS
(EHS- conditions see left column)
MidiBoom: P/N: 9120-48-11
FlexBoom: P/N: 9120-28-11
MicroBoom: P/N: 9120-30-11

Attention: Using a GN 9120-XX-11 with CS 410, you can't use the module of a answering machine parallel!

GN 6210




Bluetooth

P/N: 6210-01

Electronic Hookswitch EHS:
with **EHS-cord for GN 6210**
(EHS- conditions see left column)
P/N: 85-00011

GN Ellipse Premium LP
P/N: 8837-90-11
Base Station & Mobile Unit



Additional required:
Headset GN2000 or GN2100:

